

U-POL RAPTOR

Guidance notes for applying U-POL RAPTOR onto PVC substrates.



Health and Safety: When handling PVC substrates we recommend the use of suitable gloves.

1. Ensure that substrate is clean and dry. Remove any loose flaking or unstable material.
2. Abrade surface with 200-240 grit paper.
3. Wipe down with panel wipe (U-POL SYSTEM 2000, 2001, 2002) followed by a tack cloth.
4. Mask off all areas where you do not wish to apply U-POL RAPTOR.
5. Apply one coat of U-POL GRIP#4 and allow to dry as instructed.
6. Mix U-POL RAPTOR in accordance with instructions FILL-SHAKE-SHOOT.
7. Allow U-POL RAPTOR to dry as per the instructions.

The information contained in this document is based on present technical knowledge, and it is the responsibility of the user to take all necessary steps to ensure the suitability of the product for the intended purpose.